

AD02 Battery Check / Replace

- 1 Turn off the mains power to the unit
- 2 Carefully remove the battery.
- 3 Check the voltage reads 3 volts DC
- 4 Turn unit back on after 5 minute delay without battery
- 5 After 1 minute turn off the mains power to the unit.
- 6 Carefully replace the battery
- 7 After another 1 minute delay power the unit back on with the new battery fitted

This will ensure that the memory is completely cleared on the board.