

## Procedure for starting units after "Airflow Fail" (Trend IQ Controller)

1. Mute alarm
2. Go to SWITCH 12 "AIRFLOW FAIL RESET" in controller menu
3. Place cursor over the word "OFF"
4. Press the up arrow to change to "ON"
5. The controller may ask for the PIN code (this is normally 4648) Use the up and down arrows to change each number, moving across to the next number with the right arrow button.
6. After entering the final number, press the right arrow once more, the cursor will move to the word "OFF" now press the up arrow to change the "OFF" to "ON".
7. When the unit re-starts ensure that the relay marked "AFR" is energised. This shows the correct operation of the "Airflow Switch" (if the relay is not energised the airflow switch dial will require adjusting to a lower value).
8. Finally, change the "AIRFLOW FAIL RESET" value back from "ON" to "OFF".

### **Please note:**

Check the correct operation of the "AIRFLOW SWITCH" by switching off fan for approximately ten seconds. Ensure that the "AFR" relay de-energises. This should then re-energise when the fan MCB is switched back on.